

# Readme.Txt

## Introduction

The 2015 release of the Trovato Evaporator software is contained on this removable memory device.

This drive contains the following folders:

Drivers  
Install  
Trovato.Backup

The **Drivers** folder contains the Labjack drivers that would be needed to reinstall all of the Trovato software. It also has offline installers for Adobe Reader and Google Chrome.

The **Install** folder has two sub-folders: TrovatoEvap-C-Install and TrovatoEvap-T-Install. These folders contain all of the installation files for a system. A cryo-pump based system will use the -C- version and a Turbo pump based system will use the -T- version. The path for the install program is shown as:  
Cryo-based: \Install\TrovatoEvap-C-Install\Volume\setup.exe  
Turbo-based: \Install\TrovatoEvap-T-Install\Volume\setup.exe

The **Trovato.Backup** folder is provided to use a new feature included in this release of software. The ability to backup and restore the machine and experiment databases. Please read more about this feature in the Main Panel.pdf in the Trovato Manual folders found on the desktop after installation.

## Install

Running the setup.exe program will start the upgrade of the Trovato Evaporator software. The setup program will also install a custom version of the TeamViewer software and a folder with all the latest Trovato Manuals on the Desktop. Please review these manuals to discover new features and changes to previous features.

During the install process a Dialog will appear asking to overwrite different file types. For this upgrade please keep the default selection to overwrite the Lib files ONLY. If you overwrite the Ini or DB files you will lose your database and settings that are customized for your system.

Once the database has been opened and the SysConfig program is initialized.

You should press the SAVE button to save any changes made to the database. Then in the File menu, select the Exit menu item to close the SysConfig program.

It is highly advised to reboot the computer at this time. Failure to reboot can cause erratic operation of the TrovatoEvap software. When the reboot is complete you can launch the TrovatoEvap program using the icon on the Desktop. It a good practice to backup the database at this time and then on a regular schedule (Trovato suggests weekly) going forward.